

FIG. 1




FIG. 2




FIG.3




FIG. 4




FIG. 5




FIG. 6

550

setting

setting of connected device

562

display remote controller name

BS digital

full size 9 characters

up to half size 18 characters

563

Maker

not set

Shinagawa Denki

Umeshita Denki

Nageshiba

Medachi

Mitsuaoi

Bikuta

Maker

video-5

video-6

BS digital

digital CS-1

digital CS-2

digital CS-3

cable TV

Select maker and machine type of connected device

In order to operate device with remote controller, set AV mouse

541

OK

resign

FIG.7




FIG. 8



9/15




FIG. 9

10/15




FIG. 10

11/15




FIG. 11

12/15




FIG.12




FIG. 13




FIG. 14




FIG. 15